

EDGE ROUND

User Instructions

General use

- The product is designed for indoor use only.
- Its surface can become hot during extended operation, therefore do not cover the product.

Cleaning instructions

- Before cleaning, ensure that the power supply is switched off.
- Wipe surface of lamp shade with a soft cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, household glass cleaner or cellulose thinners.

Safety precautions

- The appliance should be installed, connected and tested by qualified electrician and in accordance with local regulations.
- Turn off the power supply before installation or maintenance of the lamp, and make sure that the cables are not squeezed or damaged by sharp edges during installation.
- The lamp should not be covered by insulation blankets or similar materials.



International warranty

Your product has been thoroughly tested to meet high quality standards and is covered by a 7-year warranty from the date of the original retail purchase. The warranty applies to defects in materials and workmanship when the product is used as intended and in line with published LIGHT-POINT guidelines.

These guidelines include but are not limited to information contained in technical specifications, safety instructions and quick start guides. LIGHT-POINT is not responsible for damage arising from failure to follow instructions relating to the use of the product.



LIGHT-POINT is a registered trademark of NORDIC LIVING GROUP.

For more information, please visit
LIGHT-POINT.COM




ON / OFF

swipe your hand under the sensor



DIMM*

hold your hand still under the sensor to adjust the light level



2700K ↔ 5000K

TUNABLE WHITE

wave your hand under the sensor forth and back in one slow movement to activate the color temperature cycle. When you see your preferred colour temperature, repeat the hand wave motion under the sensor to set the desired colour temperature.

**This product cannot be controlled by external trailing-edge dimmer*

LIGHT-POINT Smart Tune

powered by Casambi

For details on how to connect the lamp to your smartphone or tablet, please visit:

<https://light-point.com/en/smart-tune>


NOTE: Casambi installation guides and the knowledge base are available via the link above or by scanning the QR code below.



SMART TUNE™
POWERED BY CASAMBI



1




Installation instructions

NOTE: Please make sure the power supply is turned off before installing the lamp.

- A:** Hold the ceiling base to the desired location, and mark the drilling points for the screws.
- B:** Drill into the marked drilling points using a $\varnothing 6$ mm drill bit.
- C:** Fix the raw plugs so its flush against the surface.


3



- F:** Connect the cables from both the lamp and the mains power into the terminal as illustrated above.


NOTE: The ceiling/lamp base can be used as installation box.

5




- H:** Mount the decorative ceiling base cover with the magnet fixing points illustrated.

2




- D:** Place the ceiling base into the correct mounting position and pullout the mains power cable.
- E:** Screw the ceiling base securely into position.

4



- G:** To adjust the cable height, push the metal cable adjuster and either pull or feed the cable to the desired length. Release the cable adjuster to secure the cable.

6



- I:** Installation is complete

Dimmable with*:

- Integrated LIGHT-POINT SMART TUNE Powered by Casambi
- Integrated Touchless sensor
- External Casambi compatible switches

*This product cannot be controlled by external trailing-edge dimmer