

TWIST WALL

User Instructions

TWIST Collection

TWIST W1


290300, 290301, 290302, 290303, 290304

TWIST W2

290310, 290311, 290312, 290313, 290314

TWIST W3

290320, 290321, 290322, 290323, 290324



General use

- The product is designed for indoor use only.
- Do not cover the product as its surface can become hot during extended operation.

Cleaning instructions

- Before cleaning, ensure that the power supply is switched off.
- Wipe the surface of the lamp with a soft cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, household glass cleaner or cellulose thinner.

Safety precautions

- The appliance should be installed, connected and tested by a qualified electrician and in accordance with local regulations.
- Turn off the power supply before installation or maintenance of the lamp, and make sure that the cables are not squeezed or damaged by sharp edges during installation.
- The luminaire should not be covered by insulation blankets or similar materials.


International warranty

- Your product has been thoroughly tested to meet high quality standards and is covered by a 7-year warranty from the date of the original retail purchase. The warranty applies to defects in materials and workmanship when the product is used as intended and in line with published LIGHT-POINT guidelines.
- These guidelines include but are not limited to information contained in technical specifications, safety instructions and quick start guides.
- LIGHT-POINT is not responsible for damage arising from failure to follow instructions relating to the use of the product.

LIGHT-POINT is a registered trademark of NORDIC LIVING GROUP.

For more information, please visit

LIGHT-POINT.COM




IP20
 **CLASS I**



Installation instructions


NOTE: Please make sure the power supply is turned off before installing your new luminaire.

Follow the steps below to mount the lamp:



1. Hold the backplate in the desired position and mark the drilling points for the screws.


* The distance between the mounting points for each luminaire version (W1, W2, and W3) is shown in the backplates illustrations below.




2. Drill at the marked points and insert suitable wall anchors. Then pull the power cable through the backplate.

For different types of walls, we recommend consulting a professional before installation.


3. Mount the backplate securely in place with two screws of sufficient strength.



4. Connect the wires from both the lamp and the mains power to the terminals.



5. Set the colour temperature before completing the installation. You can choose between 2700K and 3000K using the integrated switch on the back of the luminaire.




6. Place the luminaire onto the backplate and secure it with the four screws using the enclosed Allen (hex) key, as illustrated.


Turn on the main power. The installation is complete.

In case of any doubt please contact a qualified electrician.


*Backplates



TWIST W1



TWIST W2



TWIST W3