

VELVET



S1400

S1800

User Instructions

LIGHT-POINT
COPENHAGEN

VELVET Pendant



VELVET S1400

280941, 280942, 280943, 280944

VELVET S1800

280951, 280952, 280953, 280954

General use

- The product is designed for indoor use only.
- Do not cover the product as its surface can become hot during extended operation.

Cleaning instructions

- Before cleaning, ensure that the power supply is switched off.
- Wipe the surface of the lamp with a soft cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, household glass cleaner or cellulose thinner.

Safety precautions


- The appliance should be installed, connected and tested by a qualified electrician and in accordance with local regulations.
- Turn off the power supply before installation or maintenance of the lamp, and make sure that the cables are not squeezed or damaged by sharp edges during installation.
- The luminaire should not be covered by insulation blankets or similar materials.

International warranty

- Your product has been thoroughly tested to meet high quality standards and is covered by a 7-year warranty from the date of the original retail purchase. The warranty applies to defects in materials and workmanship when the product is used as intended and in line with published LIGHT-POINT guidelines.
- These guidelines include but are not limited to information contained in technical specifications, safety instructions and quick start guides.
- LIGHT-POINT is not responsible for damage arising from failure to follow instructions relating to the use of the product.



LIGHT-POINT is a registered trademark of NORDIC LIVING GROUP.

For more information, please visit
LIGHT-POINT.COM




Installation instructions

⚠ Turn off the circuit breaker before starting the installation.




Connect the wires from both the lamp and the mains power to the terminals.




Adjusting cable length:
Measure the desired cable length and cut it. Remove the protective layers from the cut end as illustrated, then use two cable connectors to connect each wire to the matching wires by colour.

Choose the appropriate method based on your desired installation:


2a Mount using one cable holder unit together with the ceiling base.



2b Mount using two cable holder units.
The ceiling base may be positioned elsewhere.






Refer to the final step for the distance between the mounting points.*



Before completing the installation, select the colour temperature using the integrated switch on the back of the ceiling base:


2700K - Warm white
3000K - Neutral warm white



Drill at all marked points. Insert suitable wall anchors, then feed the power cable through the ceiling plate.

Fix the ceiling plate and cable holder unit(s) firmly in place using screws of sufficient loadbearing strength.

Consult a professional to select the appropriate wall anchor for your wall type.




The enclosed interchangeable end caps - in various colours - can be replaced during installation or at any time afterwards, as long as the main power supply is switched off.

Turn on the main power. The installation is complete.

In case of any doubt please contact a qualified electrician.

Ceiling plate dimensions



*Distance between mounting points

VELVET S1400: 132 cm (in both installation methods),
VELVET S1800: 172 cm (in both installation methods).