


STRIPE S Collection

STRIPE S pairs a minimalistic form with a beautifully anodised finish in five colors. Its switch tune function lets you adjust the light tone to fit the room and mood. Even with its thin profile, it delivers strong performance and a clean, modern expression.



SWITCH  TUNE™




STRIPE

S1500 & S2000

User Instructions




Backplate mounting points



Installation instructions

- Before starting the installation, switch off the power.
- Install the product by following the steps indicated in the illustration.
 - A** Loosen the cable retainer, set the desired cable length, and tighten it.
 - B** Prepare the mounting points in the chosen position for the ceiling box.
 - C** Use surface-appropriate anchors and fix the backplate to the ceiling with screws.
 - D** Measure 10 cm of cable from the side of the base and cut it. Using three WAGO 221 connectors (not included), connect each wire to its matching wire from the terminal block. Remove any excess cable.
 - E** Connect the power cables to the terminal block using the three WAGO 221 connectors supplied in the package.
 - F** Attach the ceiling base to the backplate using the set screws.
- Once all steps are complete and all screws are secure, restore power.

NOTE: In case of any doubt, please contact a qualified electrician.



General use

- The product is intended for indoor use only.
- Its surface can become hot during extended operation, therefore do not cover the product.

Cleaning instructions

- Before cleaning, ensure that the power supply is switched off.
- Wipe surface of lamp shade with a soft cloth.
- Do not use any abrasive cleaning tools such as steel wool, scouring sponges or stiff brushes.
- Never use strong cleaning agents such as white spirit, household glass cleaner or cellulose thinners.

Safety precautions

- The appliance should be installed, connected and tested by qualified electrician and in accordance with local regulations.
- Turn off the power supply before installation or maintenance of the lamp, and make sure that the cables are not squeezed or damaged by sharp edges during installation.
- The lamp should not be covered by insulation blankets or similar materials.

International warranty

Your product has been thoroughly tested to meet high quality standards and is covered by a 7-year warranty from the date of the original retail purchase. The warranty applies to defects in materials and workmanship when the product is used as intended and in line with published LIGHT-POINT guidelines.

These guidelines include but are not limited to information contained in technical specifications, safety instructions and quick start guides. LIGHT-POINT is not responsible for damage arising from failure to follow instructions relating to the use of the product.

LIGHT-POINT is a registered trademark of NORDIC LIVING GROUP.

For more information, please visit
LIGHT-POINT.COM

